

# How to Best Use AFFMAT™ Antimicrobial Floor Mats

Never put AFFMATs on a wet floor.

When floor is dry, peel off protective coating from adhesive tape on the underside of the AFFMAT, put mat in place and stand directly over adhesive strip area to anchor.

Mop around AFFMATs – not over them.

Do not mop under AFFMATs until you are ready to replace with a new mat.

AFFMATs are disposable and should not be “hosed off”

They will not dry and will lose their antimicrobial properties.

Set up and adhere to a replacement schedule.

When replacing AFFMAT floor mats, clean entire area with an enzyme-based floor cleaner. When sanitized area is dry, anchor a fresh, new AFFMAT.

Dispose of used AFFMATs by normal waste management collection.

AFFMATs are non-toxic.

Adherence to the above recommendations will keep restrooms appearing clean, odor-free, reduce slips and falls and lower maintenance costs.

## AFFMAT™ Replacement Schedule Guidelines

*Light Traffic*  
Up to 50 uses per day

Replace every month

*Medium Traffic*  
Up to 300 uses per day

Replace every 2 weeks

*Heavy Traffic*  
300 + uses per day

Replace every week

A mandated replacement schedule is important for a successful program. The above suggested replacement schedules are only guidelines. Your particular schedule will be determined by your specific needs.